



BOSCH



EasySaw 18V-70

UNI version in carton

Cordless Cutting



Easy-to-use and lightweight jigsaw for all basic applications.

- 1** 70mm cutting depth in wood
- 2** Compact size for easy handling
- 3** Easy-to-use SDS improved for even easier keyless saw blade changes

Product Information	
Battery Voltage	18 V
Charging Type / Time	External charger
No-Load Speed	0-2600 min-1
Runtime with one battery charge	11m (with 2.5ah battery) in 18mm chipboard
Cutting depth in wood	70 mm
Cutting depth in metal/steel	6 mm
Cutting depth in aluminium	15 mm
Media IDs	361174, 360243, 360244
Video	Sell in Video German , Sell in Video English
Sustainability	Info will follow until 09/2021
Tool Dimensions	235 x 80 x 195mm
Machine Weight (excl./incl. Wolve II Battery)	1.3 kg / 1.7 kg
Producer Country	Hungary (HU)
Predecessor (Nr./Name)	First entry level CL jigsaw

Logistical Information	
Scope Of Supply	SKU
1 x saw blade T144D	2 608 663 315
Gross Weight (incl. Packaging)	1.9 kg
Waste Packaging Plastic	Approx. 5 g
Packaging Dimensions	252 x 104 x 150 mm
Pallet Dimensions	1200 x 800 x 1105 mm
Minimum Order Quantity	1 pcs.
Customs Tariff Nr.	84672290



Country	Order ID	EAN	RRP incl.VAT €
EU	0603012000	4053423229912	75,59 €