



4DPi-24-HAT

2.4" HAT Primary Display for the Raspberry Pi

Quick Start Guide

What's Included

| Ш | 4DPi-24-HAT Display Module |
|---|----------------------------|
| | Quick Start Guide |

Supporting Documents

Product brief, data sheet, CAD step model, simplified Step model, 3D-PDF model, schematic diagram and application note links are available at www.4dsystems.com.au

NOTE: Please refer to the 4D Systems website for the latest copy of 4DPi-24-HAT Data Sheet

Specifications

- Universal 2.4" Primary Display for the Raspberry Pi.
 Compatible with Raspberry Pi A+, B+ and Raspberry Pi 2.
 240x320 pixel Resolution, RGB 65K true to life colours, TFT Screen with integrated 4-wire Resistive Touch Panel.
- Display full GUI output / primary output, just like a monitor connected to the Raspberry Pi
 High Speed 48MHz SPI connection to the Raspberry Pi, featuring SPI
- High Speed 48MHz SPI connection to the Raspberry Pi, featuring SPI compression technology.
 Typical frame rate of 17 Frames per second (FPS), higher if image can be compressed further by the kernel. Lower if no compression is possible.
 Powered directly off the Raspberry Pi, no external power supply is required.
 On/Off or PWM controlled backlight, selectable by on board jumper.
 Module dimensions: 56.5 x 65 x 14.4mm weighing ~ 30g.
 Display Viewing Area: 36.72 x 74.75mm
 4x mounting holes with 2.6mm diameter for mechanical mounting.
 RoHS and CE Compliant.

Let's get Started

Hardware Connection

The 4DPi-24-HAT is easily connected t Raspberry Pi, by simply aligning the Ferr 40 way header with the Raspberry Pl's M 40 way header, and connecting th together – ensuring the aligning is con and all pins are seated fully and correctly

NOTE: The 4DPi-24-HAT is supported only by the 40 way header, and therefore pressing on the touch screen may result in the 4DPi-24-HAT moving towards the Raspberry Pi, and therefore the circuitry touching the Raspberry Pi. This could result in damage to either product if a short circuit were to occur. It is therefore highly encouraged to mount the display using standoffs (not included). Software Download / Installation



4D Systems has prepared a custom DMA enabled kernel for use with the Raspbian OperatingSystem, which is available for download as a single Debian Package. This can be installedover your existing Raspbian installation, or it can be applied over a can be insta fresh image. This Debian package will only work for the Rasbian operating system, and will not

If you are starting from scratch, start from Step 1, else skip to step 3 if you already have a Raspbian Image and which to apply this kernel to that. Please note, it is impossible for us to know what you have done to your Raspbian image, if you are not installing from scratch – so if you encounter issues, please try and use a fresh image to determine if possible modifications are conflicting with our kernel release.

1. Download the latest Raspbian Image from the Raspberry Pi website: http://downloads.raspberrypi.org/raspbian_latest

Load the Raspberry Pi image onto a SD card, using the instructions provided on the Raspberry Pi website for Linux, Mac or PC:

http://www.raspberrypi.org/documentation/installation/ installing-images/README.md

- Insert the SD card into the Raspberry PI. **Do not connect the 4DPi-24-hat yet.** You will need an external monitor / keyboard / network connection, else simply a network connection to the Pi and the rest can be done over an SSH connection. Start up the Pi with at minimum an Ethernet connection connected.
- Either log into the Raspberry Pi from your keyboard/monitor using the standard 'pi' and 'raspberry' credentials, else SSH into your raspberry Pl and log in via your SSH session. Once logged into your Raspberry Pi, you will need to download and install the kernel which supports the 4DPi-24-HAT. The following step requires 'root' access. To gain super user access, type the following command on terminal/shell/SSH.
- # sudo su
- To download and install files, enter the following commands in terminal/shell /SSH to download the kernel from the 4D Systems Server:
- wget http://www.4dsystems.com.au/downloads/4DPi, 4DPi-24-HAT/4DPi-24-HAT_kernel_R_1_0.tar.gr
 - # tar -xzvf 4DPi-24-HAT_kernel_R_1_0.tar.gz -C / By default the package is configured for Raspberry Pi2. To use the kernel on Raspberry Pi1, modify the content of /boot/config.txt.
 - # nano /boot/config.txt
 - Find and modify the following line: kernel=kernel7_hat.img

change to:

kernel=kernel_hat.img Save the changes made to /boot/config.txt.

- Booting the Raspberry Pi directly to Desktop GUI will require modification of the /etc/rc.local file.
 - # sudo nano /etc/rc.local

Add the following command line, just before the 'exit 0' line. u pi FRAMEBUFFER=/dev/fb1 startx &

8. Shutdown the Raspberry Pi safely, and remove the power.

Connect the 4DPi-24-HAT to the Raspberry Pi, and reapply power. The terminal should begin to show on the 4DPi-24-HAT, and will be ready to use once the Raspberry Pi has booted.

NOTE: Please refer to the Datasheet on the 4D Systems website for the latest instructions as the information listed in the QSG is subject to change.

NOTES

| |
|------|
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |

www.4dsystems.com.au

sales@4dsystems.com.au Sales Tech Support: www.4dsystems.com.au/support